

instructions for use

MESH BALCONY COVERS



Figure 1. Balcony cover

- The balcony cover should be fitted vertically. It is used to decorate the specific place, it also has shading, rainproof and windproof properties and should be used as intended. The cover **DOES NOT PROTECT** against falling out.
- When the summer season ends, the cover should be uninstalled, washed, dried and stored in a dry place (the fabric can be



- The cover is tensioned during installation.
- The covers should preferably be installed on the inner part of the balcony by two adults.



Figure 2. Standard finish of balcony cover (eyelets poked around).



instructions for use

MESH BALCONY COVERS

SUGGESTION FOR INSTALLATION:

1. Unfold the curtain flat in the place where it is to be hung to ensure fitting with the front side out.
2. Eyelets made along the reinforced edges of the cover are used for fitting.
3. Installation should be carried out using all the fitting eyelets available.

Installation options:

- fastening to the balcony railing with cable ties (disposable product),
- tying with sections of the rope/string/expander to the balcony railing,
- interlacing of all eyelets with a single section of rope to the balcony railing.

4. Installation should be carried out with simultaneous tensioning on the railing. Install the eyelets one after another, by fastening the top first, then the bottom, and finally attaching the sides.

Purchase the installation kit!

sample installation kits include:



Fitting accessories:

- cable ties
- expander

Haven't you found a proper set?
Are you looking for a wall, metal or
another fixing?
Ask the advisor!



Quick contact phone: 518 537 385